



Product description

The programming interface PRI 602-... USB in a switch panel housing connects a Windows PC via the USB port to the Siedle In-Home bus and the Siedle Vario bus.

Connection to the line rectifiers BNG 650-... and BVNG 650-... via ZBVG 650-...
Interface to the Siedle In-Home bus via 8-pin Western socket or via screw terminals.
Only one PRI 602-... USB can be connected to a PC.

Specifications

Operating voltage:	10–15 V AC or 10–30 V DC
Protection system:	IP 20
Ambient temperature:	0 °C to +40 °C
Horizontal pitch (HP):	3
Dimensions (mm) W x H x D:	53.5 x 89 x 60

Article information

Article designation	Article description	Colour/Material	Article no.
PRI 602-01 USB	Programming interface USB	Black	036940



Programming interface
USB
PRI 602-01 USB

Page 2

Accessories

Article designation	Article description	Colour/Material	Article no.
ZAP 3-0	Accessory terminal cover	Black	113442

Programming interface
USB
PRI 602-01 USB

Page 3





Programming interface
USB
PRI 602-01 USB

Page 4

PRI 602-01 USB Programming interface	Product information	868 kB	Download
PRI 602-... USB	Declaration of Conformity	406 kB	Download
PRI 602-... USB Driver V2.08.28.12 für Win2k, Win XP, Vista, Win 7, Win 8 (32bit/64bit)	Software	2,2 MB	Download
PRI 602-0 USB-Treiber V2.00 for Win 98 and Win ME	Software	316 kB	Download
BPS 650-0 V2.12.0 Bus programming software	Software	50,2 MB	Download